



15CH-140

Polywood Reclining Adirondack

Step 1

Unfold the Seat assembly (FIG.1)

Step 2

Attach the front legs to the seat assembly using (4) 2 1/4" bolts, washers and nuts.

Step 3

Attach the Arms using (4) 2 1/4" bolts washers and nuts.



Step 4

Attach the Back assembly using (2) 1 1/2" bolts, washers and nuts.

- ___ 1 Front leg assembly
- ___ 2 Arms
- ___ 1 Seat
- ___ 1 Back
- ___ 1 Hardware pack

TOOLS NEEDED

7/16" Wrench
Phillips head screw driver or
4mm hex key: Included

Qty.	Description
2	A - 1 1/2" Bolt
8	B - 2 1/4" Bolt
8	 1/4-20 Lock Nut
8	 1/4" Washer

All bolts are 1/4-20

